

Frame for foot electrode FE-100 with starting edge

Product Number EP0206042



Product Description

The Verification Unit is used for regular validation of the PD-400 personal tester (EP0206024).

The tolerances and limit values of the PD-400 can be checked quickly and easily.

The following resistors are located between the test plug and the safety plug or the device connection:

	Fail Low	Pass Low	Pass High	Fail Low
Wrist strap 35 M Ω	680 k Ω	816.0 k Ω	31.8 M Ω	38.2 M Ω
Footwear left 100 M Ω	91 k Ω	109.0 k Ω	91.0 M Ω	109.0 M Ω
Footwear right 100 M Ω	91 k Ω	109.0 k Ω	91.0 M Ω	109.0 M Ω

Each individual mode of the 4 modes is tested by turning the rotary switch to the desired mode (Fail Low to Fail High).
The corresponding measurement is then carried out with the contact pin.

Also available as a PRORENT rental device.

More Images

